

MicroFridge® with Safe Plug® Quick How To Guide



Checklist

Safe Plug: What Plugs in Where

- Plug the blue plug from the refrigerator into the blue outlet on the back of the microwave
- The black plug from the microwave goes directly into the wall

Student Housing or Collegiate Concepts do not provide cleaning Services for MicroFridges. Residents are responsible for maintaining the cleanliness of their units. Cleaning supplies are available at the Area Service Desk.

Temperature : Is the dial within the fridge set between zero and highest setting? If not, please set to a higher temperature and wait 2 hours for the unit to cool.

Power to Unit: Unplug black plug from the wall, are you able to plug another device into the outlet and check to see if there is power. If not, please reach out to the Area Service Desk. It is possible the breaker has been tripped.

Microwave Parts: The Microwave has a glass carousel. This is removable for cleaning

Refrigerator Parts: The Fridge has a wire shelf and transparent crisper. Both items are removable for cleaning.

Please remember to return parts into the Microwave and Fridge.

Please do not plug the blue or black cord into an extension cord.

Summary : Quick Tips

- Do not put any metal (tin foil, mugs with metallic lining, soup cans, aluminum containers, Take Out boxes with metal handles, etc.) in the microwave it will damage it
- Please be certain the dial in your refrigerator is set between min and max, this will ensure cooling is taking place
- Cover food with paper plate or paper towel to reduce food build-up inside the microwave
- Clean microwave interior every 3 months- heat glass of water inside microwave for 5 minutes, let sit for 2 minutes, then wipe clean
- Note: When you are using the microwave or the microwave door is open, the fridge will not cool and/or the fridge light will not turn on. This is normal and part of the energy efficiency feature of the MicroFridge I.E. Cooling and fridge light will resume after several minutes of microwave no longer in use and microwave door is shut.